

> [Support & Drivers](#) > [VersaLink C7020/C7025/C7030 Multifunction Printer](#)



VersaLink C7020/C7025/C7030 Multifunction Printer Support & Drivers

[Support](#)
[Drivers & Downloads](#)
[Documentation](#)
[Videos](#)
[Contact](#)

Supported Platforms:

Windows 10, Windows 10 x64,
Windows 7, Windows 7 x64,
Windows 8.1, Windows 8.1 x64

Supported Languages: Arabic, Brazilian Portuguese, Bulgarian, Catalan, Chinese (Simplified), Chinese (Traditional), Croatian, Czech, Danish, Dutch, English (Global), English (N. America), Finnish, French, French Canadian, German, Greek, Hebrew, Hungarian, Italian, Japanese, Korean, Norwegian, Polish, Portuguese, Romanian, Russian, Spanish, Swedish, Turkish, Ukrainian

Supported Products:

PrimeLink C9065/C9070
Integrated Color Server, Xerox
AltaLink C8000 Series Built-in
Controller

File Download: Xerox Smart Start – Driver Installer

- **Filename** XeroxSmartStart_1.3.35.0.exe
- **Version** 1.3.35.0
- **Date** Sep 8, 2019
- **Size** 28.5 MB

The Xerox Smart Start - Driver Installer intelligently looks at your specific system configuration and installs the appropriate drivers for printing and scanning to your Xerox device.

End User License Agreement

IMPORTANT PLEASE READ CAREFULLY BEFORE USING THIS PRODUCT: THIS SOFTWARE LICENSE AGREEMENT ("Agreement") CONTAINS THE LICENSE TERMS AND CONDITIONS FOR THE XEROX SOFTWARE AND RELATED DOCUMENTATION (collectively "Software").

IF YOU DOWNLOAD, INSTALL OR USE THE SOFTWARE, YOU AGREE TO BE LEGALLY BOUND BY THE FOLLOWING TERMS AND CONDITIONS. IF YOU DO NOT ACCEPT THESE LICENSE TERMS YOU MAY NOT DOWNLOAD, INSTALL OR USE THE SOFTWARE AND YOU MUST DELETE ANY SOFTWARE FILES ACCESSED BY YOU OR A THIRD PARTY ON YOUR BEHALF FROM ANY AND ALL COMPUTER MEMORY INTO WHICH SUCH SOFTWARE HAS BEEN LOADED OR STORED.

When used in this agreement the term "Xerox" shall mean Xerox Corporation, its operating companies, subsidiaries and affiliates.

If you are installing the Software on behalf of the end user you must agree that you are acting as an agent of the end user customer before proceeding. As agent for the end user you hereby agree that you have either; 1) read and agree to the terms of this Agreement as authorized by the end user, or 2) you have made the end user aware of the license terms and the end user has explicitly accepted them.

1. LICENSE GRANT.

a. Xerox grants to you a non-exclusive, non-transferable license to use the Software on the Xerox-brand equipment ("Equipment") on which it was delivered or, if delivered separately, on a single item of equipment. You have no other rights to the Software

Click "Accept" to download, click "Decline" to cancel.



XeroxSmartStart_1.....exe ^



WICHTIG! BITTE VOR DEM VERWENDEN DES PRODUKTS UNBEDINGT LESEN: DIESER LIZENZVERTRAG (auch als "Vertrag" bezeichnet) REGELT DIE LIZENZBEDINGUNGEN FÜR DIE XEROX-SOFTWARE UND DIE DAZUGEHÖRENDE DOKUMENTATION (als "Software" bezeichnet).

DURCH DAS HERUNTERLADEN, DIE INSTALLATION ODER NUTZUNG DIESER SOFTWARE ERKLÄRT SICH DER BENUTZER MIT DIESEM VERTRAG EINVERSTANDEN. FALLS DER BENUTZER MIT DIESEM LIZENZVERTRAG NICHT EINVERSTANDEN IST, DARF DIESE SOFTWARE NICHT HERUNTERGELADEN, INSTALLIERT ODER VERWENDET WERDEN UND SÄMTLICHE DATEIEN DER SOFTWARE MÜSSEN VON ALLEN RECHNERN, AUF DENEN DIE SOFTWARE GELADEN ODER GESPEICHERT WURDE, GELÖSCHT WERDEN.

In diesem Vertrag bezeichnet der Begriff "Xerox" die Xerox Corporation, ihre Niederlassungen, Tochtergesellschaften und Partnerunternehmen.

Beauftragt der Endbenutzer eine dritte Partei mit der Installation der Software, so muss diese zustimmen, stellvertretend für den Endbenutzer zu handeln. In diesem Fall erklärt der Handlungsbevollmächtigte des Endbenutzers hiermit, dass er 1) den Endbenutzer-Lizenzvertrag für die Software gelesen hat und diesem für den Endbenutzer zustimmt oder 2) den Endbenutzer auf den Lizenzvertrag hingewiesen hat und der Endbenutzer diesen Vertrag explizit akzeptiert hat.

1. LIZENZGEWÄHRUNG:

a. Xerox gewährt dem Benutzer eine nicht exklusive, nicht übertragbare Lizenz zur Verwendung der Software auf dem Gerät der Marke Xerox, auf dem sie geliefert wurde, oder bei separater Lieferung auf einem einzigen Gerät. Benutzer haben keine anderen Rechte an der Software und sind nicht berechtigt: (1) die Software weiterzugeben, zu kopieren, zu verändern, zu dekompileieren, zurückzuentwickeln oder Derivate der Software zu erzeugen; (2) Softwareprogramme, die im nicht aktivierten Zustand geliefert wurden, zu aktivieren oder (3)

xerox™




Drucker werden gesucht...

xerox™



Drucker wird nicht angezeigt



 Zurück

xerox™

Drucker wird nicht angezeigt

Sicherstellen, dass der Drucker eingeschaltet und mit dem Netzwerk verbunden ist. Anschließend die Suche wiederholen.

Hier kann auch die Netzwerkadresse des Druckers für eine direkte Druckersuche eingegeben oder ein Offline-Drucker installiert werden.



1.

2.




xerox™



Verbindung wird hergestellt






 Zurück

xerox™

VersaLink C7020
Xerox VersaLink C7020




1.

Drucksystem  Drucksystem des Typs 4 Drucksystem des Typs 3 (empfohlen)Treiber-PDL  PostScript PCL6 (empfohlen)TWAIN/WIA-Scannertreiber  Scantreiber nicht installieren Scantreiber installieren

Druckername

KaWo 3 - VersaLink C7020 PS

Installieren 

xerox™

VersaLink C7020
Xerox VersaLink C7020



Drucker wird installiert



xerox™

VersaLink C7020
Xerox VersaLink C7020



Installation abgeschlossen

VersaLink C7020 PS



Testseite drucken

Weitere(n) Drucker installieren

Fertig



Höchste Übereinstimmung



Systemsteuerung

App



Apps



System Configuration



Systeminformationen



Dokumente (4+)

Ordner (3+)

Einstellungen (4+)



Systemsteuerung

App

3.

Öffnen

Dateispeicherort öffnen

An "Start" anheften


An Taskleiste anheften

1.



2.


systemsteuerung








- Startseite der Systemsteuerung
- System und Sicherheit
- Netzwerk und Internet
- **Hardware und Sound**
- Programme
- Benutzerkonten
- Darstellung und Anpassung
- Zeit und Region
- Erleichterte Bedienung

 **Geräte und Drucker** 
[Gerät hinzufügen](#) | [Erweiterte Druckereinstellungen](#) | [Maus](#) | [Geräte-Manager](#) |
[Windows To Go-Startoptionen ändern](#)

 **Automatische Wiedergabe**
[Standardeinstellungen für Medien und Geräte ändern](#) | [CDs und andere Medien automatisch wiedergeben](#)

 **Sound**
[Systemlautstärke anpassen](#) | [Systemsounds ändern](#) | [Audiogeräte verwalten](#)

 **Energieoptionen**
[Energiespareinstellungen ändern](#) | [Netzschalterverhalten ändern](#) | [Energiesparmodus ändern](#) |
[Energiesparplan auswählen](#) | [Energiesparplan bearbeiten](#)



1. Rechtsklick

2.

- Öffnen
 - In neuem Fenster öffnen
- Druckaufträge anzeigen
- Als Standarddrucker festlegen
- Druckeinstellungen
- Druckereigenschaften
- Xerox-Druckereigenschaften
- Xerox-Gerätestatus
- Verknüpfung erstellen
- Gerät entfernen
- Problembearbeitung
- Eigenschaften

KaWo 3 - VersaLink C7020 PS Hersteller: Xerox Corporation Gerätestatus: 0 Dokument(e) in der Warteschlange
Modell: Xerox VersaLink C7020...
Kategorie: Drucker

Kostenzählung Konfiguration Kommunikation Verwaltung

Kostenzählung

Ein



Einstellungen

Kostenzahlungsmethode

Netzwerkcostenzählung



Standardbenutzerkennung (Optional)

Standardkostenstellennummer (Optional)

xerox™

OK

Abbrechen



Einstellungen

1.



Alle Codes verbergen

Aus



Aufforderung beim Drucken

Ein



Letzte Kostenzählungsdaten speichern

Ein



Verfolgungsoptionen

Alle Aufträge verfolgen




2.



OK

Abbrechen



Die Drucker PIN findest du auf
kawo3.de/get.php?id=1657

Beim Drucken



Support Drivers & Downloads Documentation Videos Contact

Supported Platforms:

Windows 10, Windows 10 x64,
Windows 7, Windows 7 x64,
Windows 8.1, Windows 8.1 x64

Supported Languages:

Arabic, Brazilian Portuguese, Bulgarian, Catalan, Chinese (Simplified), Chinese (Traditional), Croatian, Czech, Danish, Dutch, English (Global), English (N. America), Finnish, French, French Canadian, German, Greek, Hebrew, Hungarian, Italian, Japanese, Korean, Norwegian, Polish, Portuguese, Romanian, Russian, Spanish, Swedish, Turkish, Ukrainian

Supported Products:

PrimaLink C9065/C9070
Integrated Color Server, Xerox
AtaLink C9000 Series Sub-In
Controller

File Download: Xerox Smart Start – Driver Installer

- Filename: XeroxSmartStart_1.3.35.0.exe
- Version: 1.3.35.0
- Date Sep 8, 2019
- Size: 28.5 MB

The Xerox Smart Start - Driver Installer intelligently looks at your specific system configuration and installs the appropriate drivers for printing and scanning to your Xerox device.

End User License Agreement

IMPORTANT PLEASE READ CAREFULLY BEFORE USING THIS PRODUCT: THIS SOFTWARE LICENSE AGREEMENT ("Agreement") CONTAINS THE LICENSE TERMS AND CONDITIONS FOR THE XEROX SOFTWARE AND RELATED DOCUMENTATION (collectively "Software").

IF YOU DOWNLOAD, INSTALL OR USE THE SOFTWARE, YOU AGREE TO BE LEGALLY BOUND BY THE FOLLOWING TERMS AND CONDITIONS. IF YOU DO NOT ACCEPT THESE LICENSE TERMS YOU MAY NOT DOWNLOAD, INSTALL OR USE THE SOFTWARE AND YOU MUST DELETE ANY SOFTWARE FILES ACQUIRED BY YOU OR A THIRD PARTY ON YOUR BEHALF FROM ANY AND ALL COMPUTER MEMORY INTO WHICH SUCH SOFTWARE HAS BEEN LOADED OR STORED.

When used in this agreement the term "Xerox" shall mean Xerox Corporation, its operating companies, subsidiaries and affiliates.

If you are installing the software on behalf of the end user you must agree that you are acting as an agent of the end user customer before proceeding. As agent for the end user you hereby agree that you have either: 1) read and agree to the terms of this Agreement as authorized by the end user, or 2) you have made the end user aware of the license terms and the end user has explicitly accepted them.

1. LICENSE GRANT.

Xerox grants to you a non-exclusive, non-transferable license to use the software on the Xerox-brand equipment ("Equipment") on which it was delivered or, if delivered separately, on a single item of equipment. You have no other rights to the software.

Click "Accept" to download, click "Decline" to cancel.

[Contact Us](#) [Careers](#) [About Xerox](#) [Investors](#) [Privacy](#) [Legal](#) [Site Map](#)

© 2020 Xerox Corporation. All rights reserved. Xerox® and "Made to Think" are trademarks of Xerox Corporation in the United States and/or other countries.

Drucken

1 Blatt Papier

Ziel

KaWo 3 - VersaLink C7

Seiten

Alle

Kopien

1

Layout

Hochformat

Farbe

Schwarz-Weiß

Weitere Einstellungen

Drucken

Abbrechen

Kostenzählungsdaten zum Drucken eingeben

Benutzerkennung	Username
Kostenstellennummer	PIN

1.

2.



Druck

Abbrechen